Restore factory default

Scanning the following barcodes one by one to restore the scanner to factory defaults. (Four steps included)

1.



2.



2090107

4.



%#IFSNO\$B

PROGRAMMING BARCODES: Scan to program Netum scanner.



Manda and Discount



AT + MODE = 2

*Basic Mode(HID)



4. \$RF#ST20

Sleep Time out 10Mins



IOS Keyboard POP UP/HID